


WEIGHING IS MADE WHILE VEHICLE IS ON SCALES


Arrives full

To start the weighing process for a full vehicle, press "START: Full vehicle arrives".



Step 1.

In the opened window start filling information by adding a vehicle. Press „(no value)“ and select a vehicle from the list, confirm your choice by pressing „OK“.




START: Full vehicle arrives

Step 1 :
Select vehicle : (no value)

Step 2 :
New bruto : (no value) << Weigh

Step 3 :
Product : + (no value) 100 % kg X

Step 4 :
✓ Save data Save and print




Vehicles (outside)

Vehicle number	Vehicle brand	Vehicle tra
ABC321	Man	
ABC987	Scania	
ABC456	Volvo	

Filter: Search:


OK Cancel Nothing

You can also add a new vehicle by pressing „New“. After completing the vehicle data, press „OK“ to save the data. When you select a vehicle, press „OK“.




Step 2.

Weigh the vehicle. The weighing of the vehicle is performed by pressing „<< Weigh“.



Step 3.

Specify the load. By pressing "(no value)" you can choose a product from the list or add a new one by clicking "Add".




START: Full vehicle arrives

Step 1 :
Select vehicle : ABC321

Step 2 :
New bruto : 6237 (kg) << Weigh

Step 3 :
Product : (no value) 100 % kg

Step 4 :
Save data Save and print




Goods

Product name
Grains

Buttons: Add, Edit, Delete, Clone, Refresh, Print..., OK, Cancel, Nothing

Provide cargo data by pressing „OK“, select a load and confirm.



Edit product data

Name: Grains

Enabled: ☒

Group: (no value)

Municipality: (no value)

External code: .

Density, kg/m3: .

Price, lc/T: .

Price, Eur/T: .

Short code: .

Add. info 1: .



Add. info 2: .

Add. info 3: .

Buttons: OK, Cancel


Step 4.

Save the information. All information is saved by clicking "Save data" and confirmed by pressing "OK".




Departs empty

To start weighing the outgoing vehicle, press „FINISH: Empty vehicle departs“.



A new window will show up.




Step 1.

Select your vehicle and confirm your selection by pressing „OK“.



Step 2.

Press „<<Weigh“ to get the vehicle weight.



Step 3.

The program automatically calculates the actual net weight.



Additional info.



Fill in all required fields of additional information at your own discretion.

Customers :		Weight by documents :	
Driver :	(no value)	Tare (kg) :	
Sender :	(no value)	Bruto (kg) :	
Carrier :	(no value)	Neto (kg) :	
Receiver :	(no value)	Contract :	(no value)
Additional info 1 :		Additional info 2 :	
Card :	(no value)	Net correction :	1 >>
Container :		Distance (km) :	
External code :	<< +	Value (Ic) :	>>
Invoice number :	(no value)	Value (Eur) :	>>
Send to MAZ :	<input type="checkbox"/>	Result Group :	(no value)
Additional info 3 :		Additional info 4 :	
Additional info :		Add.In.3 :	Add.In.4 :
Additional info (2) :		Add.In.5 :	Add.In.6 :
Address FROM :	<< Sender	Add.In.7 :	Add.In.8 :
Address TO :	<< Receiver	Num. 1 :	Num. 2 :

Step 5.


Confirm the weighing by pressing „Save result“. After validating the result, the system deletes the vehicle from the existing vehicle list.

Step 5 :






Confirm

×






Save new result ?

Pressing "Save and Print" will save the weighing result and open the data print window. Pressing the print button will print a data sheet.

Step 5 :



Rezultatų ataskaita

Data: 22/05/2019 19:42:50
Programos ID: 0

Vartotojas:
Išorinis kodas:

Iš:
Papildoma info.

I:
Atstumas:

Svoris

Kaina:

Kroviny s viduje

<i>Pagal dokumentus</i>	Sverimo duomenys
Bruto	Bruto 6237
Tara	Tara 3000
Neto	Neto 3237
	Korekcija neto(±%) 0.00

Transporto priemonė

Valst. numeris	ABC123	Maks. svoris
Markė	Man	Maks. talpa
Vairuotojas	0	Trumpas kodas
		Konteinerio ID
Savininkas		
Pavadinimas	Company	PVM kodas
Išorinis kodas		Bankas
Adresas		Sąskaita
Telefonai		Nuolaida 1

Siuntėjas

Pavadinimas	PVM kodas
Išorinis kodas	Bankas
Adresas	Sąskaita
Telefonas	Nuolaida

Vežėjas

Pavadinimas	PVM kodas
Išorinis kodas	Bankas
Adresas	Sąskaita
Telefonas	Nuolaida

Gavėjas

Pavadinimas	PVM kodas
Išorinis kodas	Bankas
Adresas	Sąskaita
Telefonas	Nuolaida

Prekės

Trumpas kodas	Pavadinimas	Išorinis kodas	Tankis	Kaina
	Grains			0

Bruto Sverimas

Data	21/05/2019 02:25:51	Programos ID	0
Sverimo metodas	8	Sverimo tipas	2
Vartotojas	SYSDBA	Vežėjo ID	
Greitis	0	Krovinio ID	
Svoris pagal ašys	Ašis	Svoris (kg)	
	1	6237	
Bruto		6237 kg	

Taros Sverimas

Data	22/05/2019 19:13:24	Programos ID	0
Sverimo metodas	8	Sverimo tipas	2
Vartotojas	SYSDBA	Vežėjo ID	
Greitis	0	Krovinio ID	
Svoris pagal ašys	Ašis	Svoris (kg)	
	1	3000	
Tare		3000kg	